

Overall maximum width for each size is measured from the outer edge to outer edge of the lenses. If the maximum width of your eyewear exceeds this measurement, choose a larger size.

SIZING GUIDE INSTRUCTIONS:

- 1 CHOOSE THE LENS SHAPE:**
To use the sizing guide, print out this form at 100% actual size and then place your prescription glasses face down on the models to determine which best matches your eyewear.
- 2 CHOOSE THE SIZE:**
Each model is available in multiple sizes. Choose the size that is closest to your eyewear.
- 3 CHOOSE THE BRIDGE SIZE:**
There are three different bridge prong depths. Measure the thickness of your eyewear frame bridge (see the below image for reference). Choose the smallest depth for frames with a very thin bridge (< 2.75 mm), the medium depth for slightly thicker bridges (2.76-4 mm), and the large for bridges (4-5.75 mm).



Measure the thickness of your eyewear bridge to determine the appropriate Snap-On bridge size



The image of the coin should be the same size as an actual coin when the document is printed at full size. The image of the coin should be 24 mm in diameter at full size.

<p>MODEL 70 Maximum Width Size 56: 131 mm Size 58: 133 mm Size 60: 137 mm</p>		<p>Size Lens Width 56 58 60</p>
<p>MODEL 72 Maximum Width Size 55: 127 mm Size 57: 131 mm Size 59: 136 mm</p>		<p>55 57 59</p>
<p>MODEL 75 Maximum Width Size 56: 130 mm Size 58: 134 mm Size 60: 138 mm</p>		<p>56 58 60</p>
<p>MODEL 76 Maximum Width Size 56: 130 mm Size 58: 134 mm Size 60: 138 mm</p>		<p>56 58 60</p>
<p>MODEL 77 Maximum Width Size 55: 128 mm Size 57: 132 mm Size 59: 136 mm</p>		<p>55 57 59</p>
<p>MODEL 80 Maximum Width Size 55: 131 mm Size 57: 135 mm Size 59: 139 mm</p>		<p>55 57 59</p>